



A NEW DIMENSION IN PRINT AND CUT_



UV-LED

HIGH-DEFINITION
OUTPUT

SPECIAL EFFECTS



The most advanced generation of TrueVIS

- ECO-UV inks and premium UV print technology make the MG ideal for branching into professional UV print and cut.
- High-quality components, time-saving RIP features and simple media handling make the MG perfect for printing short runs, long runs, print/cut, and so much more.



User-friendly features—with you in mind

- Easy-to-operate control panel.
- Optional take-up unit enables unattended printing.
- ▶ Optional extension table lets users print onto semi-rigid card stock.



Expanded print expression

- Available ink configurations to meet your customers' needs—from brand accurate colors to high-end, premium gloss and texture effects.
- Combine Orange and Red inks to push the color boundaries of digital printing.
- High opacity white ink formulated to produce high-quality window graphics with economical ink usage.

Additional Features

- + Included VersaWorks 6 RIP—featuring new True Rich Color 3 preset, Nearest Color Finder, and Variation job function.
- + Roland DG Connect App ready—giving you instant access to important data about print jobs as well as your business.
- + A variety of available ink configurations expand your capabilities to include rich colors and interesting spot UV effects.
- + One-pass multilayer printing functionality lets users produce exciting print output with ease.

Technical Specs

		MG-640	MG-300
Size		64 inch	30 inch
Dimension		111 × 31 × 52 in. (2,819 × 781 × 1,316 mm)	77 × 31 × 52 in. (1,945 × 781 × 1,316 mm)
Media	Width	8.3 to 64 in. (210 to 1,625 mm)	7.2 to 30 in. (182 to 762 mm)
	Thickness	Max. 39.3 mil (1.0 mm) with liner, for printing Max. 15.7 mil (0.4 mm) with liner and 8.6 mil (0.22 mm) without liner, for cutting	
	Roll outer diameter	Max. 8.2 in. (210 mm)	
	Roll weight	Max. 88 lb. (40 kg)	Max. 55 lb. (25 kg)
	Core diameter	3 in. (76.2 mm) or 2 in. (50.8 mm)	
lnk	Colors	Eight colors (Cyan, Magenta, Yellow, Black, Orange, Red, White, Gloss) and Primer, Decal Release Primer	
	Capacity	220/500 ml cartridge (ECO-UV)	
	Configurations	CMYKOrReWhGI CMYKOrReWhWh CMYKOrReWhPr CMYKReWhGIPr CMYKWhGIGIDe CMYKWhWhGIFr CMYKWhWhGIFI CMYKWHWHGIGI	
Resolution		Max. 1,400 dpi	
RIP (included)		VersaWorks	
Cutting	Cut pressure	500 gf	
	Cut speed	0.39 to 11.8 in/s (10 to 300 mm/s)	



Built to build your business and engineered to a higher standard, the TrueVIS MG series is supplied with a Two-Year Trouble-Free Warranty* for added peace-of-mind.

Registration within 60 days of purchase and continuous exclusive use of Roland DG ink during the first two years of ownership are required to qualify for the free second year of limited warranty coverage.